

AUDIO PATCH ID

draft r01 r02 r03 r04 r05 r06 r07 r08 r09
 12 déc. 14 janv. 18 janv. 23 janv. 24 janv. 24 janv. 25 janv. 4 fev. 4 fev.

	A-001	A-002	A-003	A-004	A-005	A-006	A-007	A-008	A-009	A-010	A-011	A-012	A-013	A-014	A-015	A-016	A-017	A-018	A-019	A-020	A-021	A-022	A-023	A-024
A	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
AUDIO	DOWN STAGE RIGHT PROSCENIUM (DS-R)																							
	MIC 01	MIC 02	MIC 03	MIC 04	MIC 05	MIC 06	MIC 07	MIC 08	MIC 09	MIC 10	MIC 11	MIC 12	MIC 13	MIC 14	MIC 15	MIC 16	MIC 17	MIC 18	MIC 19	MIC 20	MIC 21	MIC 22	MIC 23	MIC 24
	N	N	N	N	N	N	N	N																
B	IN 01	IN 02	IN 03	IN 04	IN 05	IN 06	IN 07	IN 08	IN 09	IN 10	IN 11	IN 12	IN 13	IN 14	IN 15	IN 16	IN 17	IN 18	IN 19	IN 20	IN 21	IN 22	IN 23	IN 24
AUDIO	MICROPHONE LEVEL INPUTS (-60dB) SOUND BOOTH CONSOLE																							
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
	A-025	A-026	A-027	A-028	A-029	A-030	A-031	A-032	A-033	A-034	A-035	A-036	A-037	A-038	A-039	A-040	A-041	A-042	A-043	A-044	A-045	A-046	A-047	A-048

	A-049	A-050	A-051	A-052	A-053	A-054	A-055	A-056	A-057	A-058	A-059	A-060	A-061	A-062	A-063	A-064	A-065	A-066	A-067	A-068	A-069	A-070	A-071	A-072				
C	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24				
AUDIO	RTN 01	RTN 02	RTN 03	RTN 04	RTN 05	RTN 06	RTN 07	RTN 08	RTN 09	RTN 10	RTN 11	RTN 12					DOWN STAGE LEFT PROSCENIUM (DS-L)											
																		MIC 25	MIC 26	MIC 27	MIC 28	MIC 29	MIC 30	MIC 31	MIC 32			
D	RTN 13	RTN 14	RTN 15	RTN 16	RTN 17	RTN 18	RTN 19	RTN 20	RTN 21	RTN 22	RTN 23	RTN 24	L	R	L	R	IN 01	IN 02	IN 03	IN 04	IN 05	IN 06	IN 07	IN 08				
AUDIO	WALL	PRODUCTION	DESK	LIGHTING	BOOTH	STUDIO BOOTH	(NAPIER)	ROH	LEFT	RIGHT	SOUND BOOTH CONSOLE		LINE LEVEL INPUTS (+4dB) SOUND BOOTH CONSOLE															
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24				
	A-073	A-074	A-075	A-076	A-077	A-078	A-079	A-080	A-081	A-082	A-083	A-084	A-085	A-086	A-087	A-088	A-089	A-090	A-091	A-092	A-093	A-094	A-095	A-096				

	A-097	A-098	A-099	A-100	A-101	A-102	A-103	A-104	A-105	A-106	A-107	A-108	A-109	A-110	A-111	A-112	A-113	A-114	A-115	A-116	A-117	A-118	A-119	A-120	
E	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
AUDIO	SOUND BOOTH CONSOLE												CD PLAYER 1 OUT		CD PLAYER 2 OUT										
	MAIN PGM OUT		MONO OUT		SUB OUTPUTS				AUX OUTPUTS						L	R	L	R							
	L	R	MAIN	LOOP	SUB 1	SUB 2	SUB 3	SUB 4	AUX 1	AUX 2	AUX 3	AUX 4	AUX 5	AUX 6			L	R	L	R					
	N	N	N	N	N	N	N	N	N	N							N	N	N	N					
F	IN 1	IN 2	IN 1	IN 2	IN 1	IN 2	IN 1	IN 2	IN 1	IN 2	IN 1	IN 2	L	R	L	R	IN 09	IN 10	IN 11	IN 12	IN 13	IN 14	IN 15	IN 16	
AUDIO	BEHRINGER EQ	BEHRINGER EQ	BEHRINGER EQ	BEHRINGER EQ	BEHRINGER EQ	BEHRINGER EQ	BEHRINGER EQ	BEHRINGER EQ	BEHRINGER EQ	BEHRINGER EQ	BEHRINGER EQ	BEHRINGER EQ	AUX RETURN 3		AUX RETURN 4		LINE LEVEL INPUTS (+4dB) SOUND BOOTH CONSOLE								
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
	A-121	A-122	A-123	A-124	A-125	A-126	A-127	A-128	A-129	A-130	A-131	A-132	A-133	A-134	A-135	A-136	A-137	A-138	A-139	A-140	A-141	A-142	A-143	A-144	

	A-145	A-146	A-147	A-148	A-149	A-150	A-151	A-152	A-153	A-154	A-155	A-156	A-157	A-158	A-159	A-160	A-161	A-162	A-163	A-164	A-165	A-166	A-167	A-168	
G	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
AUDIO	BEHRINGER EQ		BEHRINGER EQ		BEHRINGER EQ		BEHRINGER EQ		BEHRINGER EQ		BEHRINGER EQ			BEHRINGER DEQ2496			BEHRINGER DEQ2496		BEHRINGER DEQ2496		BEHRINGER DEQ2496		HOUSE PGM MIC. PREAMP OUT		
	DEQ2496-1		DEQ2496-2		DEQ2496-3		DEQ2496-4		DEQ2496-5		DEQ2496-6			DEQ-1	DEQ-2	DEQ-3	DEQ-1	DEQ-2	DEQ-3	DEQ-1	DEQ-2	DEQ-3	DEQ-1	DEQ-2	
	OUT 1	OUT 2	OUT 1	OUT 2	OUT 1	OUT 2	OUT 1	OUT 2	OUT 1	OUT 2	OUT 1	OUT 2					1	2	1	2	1	2	1	2	
	N	N	N	N	N	N			N	N													N	N	
H	L	R	C1	C2	L	R			L	R				RTA / MIC IN		1	2	1	2	1	2	1	2	IN	AUDIO IN
AUDIO	FRONT SPEAKER		CENTRE SPEAKER		REAR SPEAKER				SUBWOOFER					BEHRINGER DEQ2496		BEHRINGER DEQ2496		BEHRINGER DEQ2496		BEHRINGER DEQ2496		PGM SOUND		RF MODULATOR	
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
	A-169	A-170	A-171	A-172	A-173	A-174	A-175	A-176	A-177	A-178	A-179	A-180	A-181	A-182	A-183	A-184	A-185	A-186	A-187	A-188	A-189	A-190	A-191	A-192	